DC331 LED Automatic Aerosol Dispenser

Instruction Manual:

GREEN LED ON ON BUTTON 7.5 7.5 MIN INTERVAL SPRAY
SENSOR LED OFF OFF BUTTON 15 15 MIN INTERVAL SPRAY
RED LED DEMO DEMO BUTTON 30 30 MIN INTERVAL SPRAY

24H 24 HOURS
NITE NIGHT TIME
DAY DAY TIME

1. ON / OFF SWITCH

SWITCH FROM OFF TO ON, MOTOR ACTIVATE, AT OFF POSITION, MOTOR WILL NOT ACTIVATE.

POWER L.E.D / SENSOR / SPRAY

- a) WHEN GREEN LIGHT ON, VISUAL INDICATOR SHOWS THE BATTERY IS OPERATING.
- b) RED LIGHT BLINKS DURING SPRAY TO INDICATOR CIRCUITRY IS FUNCTIONING PROPERLY.

3. SELECTOR BUTTON

- a) 24HR
- OPERATES 24 HOURS A DAY
- b) DAY
- FUNCTIONS ONLY WHEN LIGHT IS SENSED.
- STOPS AUTOMATICALLY WHEN AREA IS DARK.
- c) NIGHT
- FUNCTIONS ONLY WHEN AREA IS DARK.
- STOPS AUTOMATICALLY WHEN LIGHT IS DETECTED.

4. SPRAY TIME INTERVAL

7.5 MIN, 15 MIN, 30 MIN

Mounting Instruction LED Aerosol Dispenser

- 1. Pull out key plus assembly to open cabinet.
- 2. Remove front cover pulling from top.
- 3. Select spray time internal-from 7.5, 15 and 30 minutes.
- 4. Select the desired operation mode with inner switch.

24 hrs: to run 24 hrs a day

Night: for night sensor feature

Day : for day sensor feature

- 5. Drill hole as marked with 3/16" drill bit.
- 6. Insert plastic anchors provided into hole and push completely into position
- 7. Secure mounting bracket to wall with screws provided.
- 8. Insert two "AA" cell batteries into units.

Caution

Switch must be in "OFF" mode to prevent premature spraying when inserting batteries.

- 9. Insert aerosol can.
- 10. Shut cover.
- 11. To activate the unit turn outer switch to "ON" position.