# Descaler



Date of Update: 13/12/2016

Version: C

## **Product Description**

Keno™lux Decalc is an acid cleaner for the removal of scale on kitchen equipment, materials and dishwashers.

## **Properties**

Keno<sup>™</sup>lux Decalc is an acid cleaner for the removal of scale in and on kitchen equipment, materials, including dishwashers, water baths, boilers, steamers, tea and coffee kettles,...

Keno<sup>™</sup>lux Decalc is a combination of organic acids and non-ionic surface active materials for an effective decalcification of all kinds of surfaces.

Depending on the hardness of the water, Keno™lux Decalc can be used weekly or periodically.

### **Direction of use**

For all equipment:

- 1. Use Keno™lux Decalc in concentrations of 3-5% (300-500mL per 10L water) depending on the degree of the calcium scale.
- 2. Fill the object or dip it in the solution until the scale is resolved.
- 3. Rub if necessary to remove persistent scale.
- 4. Rinse thoroughly with clean water and let dry.

#### For dishwashers:

- 1. Turn off the dosing pump.
- 2. Fill the washing tank with water.
- 3. Pour enough Keno™lux Decalc in the water: 3-5% (300-500ml per 10L water).
- 4. Let the machine work for 10-15 minutes.
- 5. Empty the machine and check for a while.
- 6. Repeat if necessary.
- 7. Empty and rinse thoroughly.
- 8. Let it dry with the closing valve open.
- 9. Turn on the dosing pump.

## **Specifications**

Physical state Liquid

Colour Colourless to light yellow

pH 2.5 (1%)
Relative density ca. 1.1
Solubility in water 100 %

## Storage and Disposal

Keep only in the original container in a cool, well ventilated place. Keep container closed when not in use. Dispose in a safe manner in accordance with local/national regulations.

## Safety instructions for the user

Avoid contact between alkaline and acid products.

Always test the product first on a small surface.

Consult your CID LINES sales' person for a suitable cleaning- and disinfecting program that is adjusted according to the contamination and the specific conditions of the company.

Before use, please check the MSDS.

Not all CID LINES products are available in all countries. For information about availability of a specific product, please contact your CID LINES dealer

Waterpoortstraat 2, 8900 leper (Belgium) • T +32 (0)57 21 78 77 • F +32 (0)57 21 78 79 • Info@cidlines.com • www.cidlines.com

OHOMOR OF COMMON OF